




Hozelock UK Garden Irrigation & Automatic Watering Systems



AC1

QUICK REFERENCE



HOZELOCK AQUA CONTROL 1 WATER TIMER WATERS ONCE A DAY, EVERY DAY

Please follow the instructions to make sure that you get the most from your timer for simple and efficient watering.

INSTALLING THE BATTERIES

1. Remove screws and back cover.
2. Insert two 1.5V 'C' Alkaline batteries. (Check + and - are correct.). **IMPORTANT:** Rechargeable batteries must not be used.

3. Replace batteries each season. (max 12 months use)

MAINTAINING THE WATERPROOF SEAL

1. Ensure that rubber seal is positioned correctly.
2. Replace back cover and screw down tightly
3. Repeat each time back cover is removed

HOW TO PROGRAMME THE TIMER

There are two watering operations - Automatic and Manual.

AUTOMATIC OPERATION

Automatic ON

1. Turn dial clockwise to **AUTO START** at actual desired start time (e.g. To start watering each day at 3:00pm you must set your AC1 when the actual time of day is 3:00pm). The timer has now memorised the auto start time until it is reset and will operate every day at this time. Use of manual ON or OFF does not cancel memory.
2. Turn dial anti-clockwise to chosen number of minutes for watering (e.g. 30 minutes).

The timer will now automatically water for the set number of minutes every day at the set time.

Automatic OFF

Turn dial to Manual **ON** or **OFF**.

If you wish to return to Automatic watering re-select the number of minutes for watering (e.g. 30 minutes) as your auto start time is memorised until a new one is selected.

Changing start time

Turn dial clockwise to **AUTO START** at new chosen start time.

Changing watering time duration

Turn dial to new desired number of minutes for watering. Do not turn dial to **AUTO START** unless a new start time is desired.

MANUAL OPERATION

Manual ON

Turn dial anti-clockwise to **ON**.

Water will flow for 60 minutes maximum or until turned to OFF setting.

Note: After 60 minutes water shuts off. Knob will still point to ON and needs to be manually set to OFF or to desired number of automatic watering minutes.


Manual OFF

Turn dial clockwise to **OFF**.

Note: Operation is only audible when valve opens and closes. To check that timer is working, switch to manual ON or OFF to hear valve operate.

CONNECTING THE TIMER TO THE TAP

Use supplied adaptors if required. Tighten to ensure no leaks.



PROTECT YOUR WATER TIMER FROM FROST. REMOVE FROM THE TAP IN WINTER. PRODUCT NOT GUARANTEED AGAINST FROST DAMAGE. REMOVE BATTERIES WHEN NOT IN USE.

PROBLEM SOLVING

PROBLEM	SOLUTION
Valve will not open or close when dial is at ON or OFF .	Clean battery connections or replace with new batteries.
Valve works but no water flows.	Check tap is turned on.
Valve works on manual but no automatic watering.	Set Auto Start time
Knob points to ON but no watering.	Manual ON 60 minutes is finished. Switch off or turn to desired automatic watering time.